

IFP Firmware Upgrades using USB

The V7 IFP has two options for the firmware update with the downloaded file using a USD Disk (note: you can also see if there are over the air (OTA) updates available in the IFP Settings>System menu):

IFP Power Button firmware update method:

1. Extract the contents and move the folder “upgrade_xxxx” to the root folder of a FAT formatted USB disk
2. Insert the USB Drive to the IFP front right USB port
3. Power off the IFP by holding down the power button for a few seconds
4. Push and hold the power button for at least 5 seconds until the button blinks red.

IFP Admin menu firmware update method:

1. Extract the contents and move the folder “upgrade_xxxx” to the root folder of a FAT formatted USB disk
2. Insert the USB Drive to the IFP front right USB port
3. “Input 1 3 7 9” from the IFP remote to bring up the Admin DEBUG MENU
4. Go to UPGRADE in the Admin Debug Menu, then choose “Upgrade All”
5. It can take as much as 10 minutes to complete the entire installation and reboot.



The firmware update usually takes 5-10 minutes and may reboot multiple times. Please wait to make sure the firmware update is complete before touching anything on the IFP or problems can occur.