

V7 NAVIGATION 1000

Original files from backup DVD

RESTORE PROCEDURE

If you are attempting to restore the software files for Navigation 1000, it is assumed that you have basic knowledge of copying and pasting in Windows PC, browsing and downloading files from internet, selecting, formatting drives and unzipping archived folders.

Due to the size of files that will be required to download, it is preferred that you use the original backup DVD and follow the restore procedure using map loader that was included to avoid any file corruption that can be caused due to unstable internet connection issues.

V7 is not responsible for any software corruption or loss of data; end-user is responsible to make sure their software and personal data is backed up appropriately.

NOTE: These downloads are provided for customers who have lost or have damaged backup DVD.

RESTORE SOFTWARE FILES

Step 1: Before you start check system requirements

Make sure you have the following:

- Personal Computer with Hi-Speed Internet Connection
- SD card with at least 970MB of free space
- SD card reader / writer for data transfer between PC and SD card
- V7 Navigation 1000

Step 2: Format SD card

If using Windows XP:

- Select the drive letter where SD card is inserted
- Right-click and select Format
- Make sure the file system selected is FAT and start

Step 3: Download software files from internet to PC

- Download Storage_Card.zip on to PC

Step 4: Unzip (Extract) software files to SD card

Once the SD card is formatted:

- Unzip (Extract) the zip files on to root directory of SD card (**SD:**)

RESTORE / INSTALL MAPS

Step 5: Download map files to map folder

Once the files are extracted to SD card:

- Select and download the map files needed to **SD:\MyGuide\maps** directory

Step 6: Insert SD card to Navigation 1000

- Eject the SD card from PC and insert it into Navigation 1000.
- You are done at this point.